



ROK - Keramik
Robert Neuhauser
Bernerstrasse Nord 180
8064 Zürich

Telefon +41 (0)1 433 01 55 Fax +41 (0)1 433 01 84

Brand: Rohbrand

	T1	T2	T3	T4	T5	T6
	160 °C	1000 °C	1000 °C	0 °C	0 °C	0 °C
time 0	time 1	time 2	time 3	time 4	time 5	time 6
0	160 Min.	360 Min.	15 Min. Haltezeit	0 Min.	0 Min.	0 Min.

time 0	0 Min.					
time 1	0 °C	bis	160 °C	in	160 Min.	= 60.0 °C pro Stunde
time 2	160 °C	bis	1000 °C	in	360 Min.	= 140.0 °C pro Stunde
time 3	1000 °C	bis	1000 °C	in	15 Min.	= 0.0 °C pro Stunde
time 4	1000 °C	bis	0 °C	in	0 Min.	= 0.0 °C pro Stunde
time 5	0 °C	bis	0 °C	in	0 Min.	= 0.0 °C pro Stunde
time 6	0 °C	bis	0 °C	in	0 Min.	= 0.0 °C pro Stunde

Brenndauer 8 Std. 55 Min.



ROK - Keramik
Robert Neuhauser
Bernerstrasse Nord 180
8064 Zürich

Telefon +41 (0)1 433 01 55 Fax +41 (0)1 433 01 84

Brand: Keramikbrand 1'030 °C

	T1	T2	T3	T4	T5	T6
	1030 °C	1030 °C	0 °C	0 °C	0 °C	0 °C
time 0	time 1	time 2	time 3	time 4	time 5	time 6
0	360 Min.	20 Min. Haltezeit	0 Min.	0 Min.	0 Min.	0 Min.

time 0				0 Min.		
time 1	0 °C	bis	1030 °C	in	360 Min.	= 171.7 °C pro Stunde
time 2	1030 °C	bis	1030 °C	in	20 Min.	= 0.0 °C pro Stunde
time 3	1030 °C	bis	0 °C	in	0 Min.	= 0.0 °C pro Stunde
time 4	0 °C	bis	0 °C	in	0 Min.	= 0.0 °C pro Stunde
time 5	0 °C	bis	0 °C	in	0 Min.	= 0.0 °C pro Stunde
time 6	0 °C	bis	0 °C	in	0 Min.	= 0.0 °C pro Stunde

Brenndauer 6 Std. 20 Min.



ROK - Keramik
Robert Neuhauser
Bernerstrasse Nord 180
8064 Zürich

Telefon +41 (0)1 433 01 55 Fax +41 (0)1 433 01 84

Brand: Einbrandverfahren 1'150 °C

	T1	T2	T3	T4	T5	T6
	160 °C	1150 °C	1150 °C	0 °C	0 °C	0 °C
time 0	time 1	time 2	time 3	time 4	time 5	time 6
0	160 Min.	360 Min.	15 Min. Haltezeit	0 Min.	0 Min.	0 Min.

time 0	0 Min.					
time 1	0 °C	bis	160 °C	in	160 Min.	= 60.0 °C pro Stunde
time 2	160 °C	bis	1150 °C	in	360 Min.	= 165.0 °C pro Stunde
time 3	1150 °C	bis	1150 °C	in	15 Min.	= 0.0 °C pro Stunde
time 4	1150 °C	bis	0 °C	in	0 Min.	= 0.0 °C pro Stunde
time 5	0 °C	bis	0 °C	in	0 Min.	= 0.0 °C pro Stunde
time 6	0 °C	bis	0 °C	in	0 Min.	= 0.0 °C pro Stunde

Brenndauer 8 Std. 55 Min.



ROK - Keramik
Robert Neuhauser
Bernerstrasse Nord 180
8064 Zürich

Telefon +41 (0)1 433 01 55 Fax +41 (0)1 433 01 84

Brand: Keramikbrand 1'150 °C

	T1	T2	T3	T4	T5	T6
	1150 °C	1150 °C	0 °C	0 °C	0 °C	0 °C
time 0	time 1	time 2	time 3	time 4	time 5	time 6
0	360 Min.	20 Min. Haltezeit	0 Min.	0 Min.	0 Min.	0 Min.

time 0				0 Min.		
time 1	0 °C	bis	1150 °C	in	360 Min.	= 191.7 °C pro Stunde
time 2	1150 °C	bis	1150 °C	in	20 Min.	= 0.0 °C pro Stunde
time 3	1150 °C	bis	0 °C	in	0 Min.	= 0.0 °C pro Stunde
time 4	0 °C	bis	0 °C	in	0 Min.	= 0.0 °C pro Stunde
time 5	0 °C	bis	0 °C	in	0 Min.	= 0.0 °C pro Stunde
time 6	0 °C	bis	0 °C	in	0 Min.	= 0.0 °C pro Stunde

Brenndauer 6 Std. 20 Min.



ROK - Keramik
Robert Neuhauser
Bernerstrasse Nord 180
8064 Zürich

Telefon +41 (0)1 433 01 55 Fax +41 (0)1 433 01 84

Brand: Steinzeugbrand 1'250 °C

	T1	T2	T3	T4	T5	T6
	700 °C	1240 °C	1240 °C	0 °C	0 °C	0 °C
time 0	time 1	time 2	time 3	time 4	time 5	time 6
0	300 Min.	120 Min.	20 Min. Haltezeit	0 Min.	0 Min.	0 Min.

time 0	0 Min.					
time 1	0 °C	bis	700 °C	in	300 Min.	= 140.0 °C pro Stunde
time 2	700 °C	bis	1240 °C	in	120 Min.	= 270.0 °C pro Stunde
time 3	1240 °C	bis	1240 °C	in	20 Min.	= 0.0 °C pro Stunde
time 4	1240 °C	bis	0 °C	in	0 Min.	= 0.0 °C pro Stunde
time 5	0 °C	bis	0 °C	in	0 Min.	= 0.0 °C pro Stunde
time 6	0 °C	bis	0 °C	in	0 Min.	= 0.0 °C pro Stunde

Brenndauer 7 Std. 20 Min.